

# **KING** A D V E N T U R E **GRILL**



Campfire Cooking Grill BBQ Combo

## **USER MANUAL**

**PLEASE READ AND UNDERSTAND THIS MANUAL  
COMPLETELY BEFORE USE.**

## Overview

- (1) Canvas Carry Bag
- (3) Hanging Hooks
- (5) Screw-in Pole

- (2) Grill/BBQ Cooking Surfaces
- (4) Screw Clamps



## Setting Up

1. Remove all accessories from the carry bag.
2. Place accessories in desired order onto the bottom half of the pole.
3. Screw the two poles together.
4. Using the screw clamps, set and tighten the clamps to your preferred height.
5. Hammer into the ground.



---

**Note:** Take care when hammering the BBQ's centre pole into the ground. Repeated hard-hits will warp the top of the pole. We advise customers to use a soft-faced hammer or block of wood as a buffer.

---

**To utilise the maximum lifespan of steel cookware please follow these steps:**

### Before first use

1. Wash thoroughly with warm soapy water, rinse then dry completely.
2. Apply a light coating of cooking oil over all surfaces.
3. Place contents over a heat source for one hour.
4. Wipe off any excess oil and the item is ready for use.

### After each use

1. Remove any excess food.
2. Add water to all surfaces to deglaze any fats and oils.
3. Wipe all surfaces clean with paper towel.
4. Apply a light coating of cooking oil to all surfaces before storing.

12 MONTH LIMITED

# WARRANTY

## WARRANTY PERIOD:

Full 12 month warranty from date of purchase against all manufacturing defects.

---

## WHAT DOES THE WARRANTY COVER?

Under normal usage conditions, this warranty covers:

- a. Any defect in design or manufacture which results in the product failing to perform substantially as described in authorised advertising or literature.
- b. We will either repair or replace the product at our discretion providing that the fault is found to have been caused by a design or manufacturing defect and not misuse or tampering.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits provided to you as the consumer by this warranty are in addition to other rights and remedies available to you under the law.

---

## THE WARRANTY DOES NOT COVER:

- a. Any damage resulting from improper use
  - b. Faulty installation or modification made during installation
  - c. The cost of removing and reinstalling the product
  - d. Travel and /or other expenses due to customer's remote location
  - e. Transport charges and damage in transit. It is your responsibility to deliver and pick up your product, including any costs associated with the postage of your repair or replacement product. If you do freight your product we recommend that you insure against loss or damage.
  - f. Any loss directly or indirectly associated with the product failing to operate.
  - g. Damage caused by mould, insects, animals, misuse, incorrect operation, adverse weather, accidents and fair wear and tear.
- 

TO MAKE A CLAIM, PLEASE ENSURE YOU RETAIN YOUR SALES RECEIPT OF PURCHASE

# 1800 88 39 64



OUTDOOR SUPACENTRE PTY LTD  
2 Stanley St Silverwater NSW, 2128  
PHONE: 1800 88 39 64  
[www.4wdsupacentre.com.au](http://www.4wdsupacentre.com.au)