




FISHING KAYAK USER MANUAL


AKTA-2.85KAYAK_01



V1.3

**PLEASE READ AND UNDERSTAND THIS MANUAL
COMPLETELY BEFORE USING THIS PRODUCT.**

1. FEATURES



2. SAFETY WARNING

1. Warning - Danger of drowning.
2. Only use kayak on water protected from wind and rough waves.
3. Always wear a life jacket when kayaking.
4. Not for use in rough surf conditions.
5. Never kayak while under the influence of alcohol or drugs.
6. Ensure weight distribution is safe.
7. Children under 14 years must be supervised by an adult.
8. Never kayak alone. Always kayak with another adult who is a strong swimmer.
9. Remain seated at all times while kayaking.
10. Recommended not to use beyond comfortable swimming distance from shore.
11. Recommended to practise entering and re-entering (i.e. in case user falls out) the kayak safely.

3. FIRST SET-UP

PADDLE

You have been supplied with a 2 piece Kayak Paddle for easy storage and transportation. To build the paddle, push the button down, slide each end into each other, line up the button hole until the button pops up the location hole. There are 3 location holes you can choose from to suit your paddling preference.



SEAT

Your seat comes complete ready to place into the kayak. You will find straps on either side of the seat to adjust the backrest up and down to suit your comfortable seating position.



FOOT REST

It is very much personal choose where you rest your feet in a kayak and different from person to person. Your Kayak has been fitted with adjustable feet rests. To adjust, press the button at the back of the rest and push backwards or forwards to your foot's desired resting position.



4. CARE

Our kayaks are made of high-density linear polyethylene, which is virtually maintenance free. A minimal amount of care in storage and transporting will help the kayak maintain a like-new condition for many years.

CLEANING

Usually, a quick rinse of fresh water is all that is necessary to keep your hull clean and functioning in good order. This is very important after paddling in salt water, to thoroughly rinse the hull off and all your accessories.

TRANSIT

Remove adjustable rod holders, seat and any personal belongings from the kayak prior to transportation. Please ensure your kayak is safely secured before transit.

STORAGE

Be sure to empty the kayak of all water. Store indoors or in the shade. Do not store in sunlight for long periods of time.

12 MONTH LIMITED WARRANTY

WARRANTY PERIOD:

Full 12 month warranty from date of purchase against all manufacturing defects.

WHAT DOES THE WARRANTY COVER?

Under normal usage conditions, this warranty covers:

- a. Any defect in design or manufacture which results in the product failing to perform substantially as described in authorised advertising or literature.
- b. We will either repair or replace the product at our discretion providing that the fault is found to have been caused by a design or manufacturing defect and not misuse or tampering.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits provided to you as the consumer by this warranty are in addition to other rights and remedies available to you under the law.

THE WARRANTY DOES NOT COVER:

- a. Any damage resulting from improper use
 - b. Faulty installation or modification made during installation
 - c. The cost of removing and reinstalling the product
 - d. Travel and /or other expenses due to customer's remote location
 - e. Transport charges and damage in transit. It is your responsibility to deliver and pick up your product, including any costs associated with the postage of your repair or replacement product. If you do freight your product we recommend that you insure against loss or damage.
 - f. Any loss directly or indirectly associated with the product failing to operate.
 - g. Damage caused by mould, insects, animals, misuse, incorrect operation, adverse weather, accidents and fair wear and tear
-

TO MAKE A CLAIM, PLEASE ENSURE YOU RETAIN YOUR SALES RECEIPT OF PURCHASE

1800 88 39 64



OUTDOOR SUPACENTRE PTY LTD
2 Stanley St Silverwater NSW, 2128
PHONE: 1800 88 39 64
www.4wdsupacentre.com.au